


QCY T13 TWS Earphones with 4 Microphones



Overview



1. LED
2. Touch panel
3. Case button
4. LED

Choose the Right Eartips

Start with the **medium** tips—switch to larger or smaller sizes until you get a secure, comfortable seal and balanced bass response.

Controls & Functions

- Power on – Touch & hold either panel for 1.5 s
- Power off – Return both earbuds to the charging case
- Answer / end call – Double-tap either panel
- Reject call – Touch & hold either panel for 1.5 s
- Previous track – Touch & hold the left panel for 1.5 s
- Next track – Touch & hold the right panel for 1.5 s
- Voice assistant – Triple-tap the left panel
- Play / Pause – Double-tap either panel
- Low-latency (gaming) mode – Triple-tap the right panel

First-Time Pairing

1. Open the lid and *remove both earbuds*—they power on automatically.
2. On your phone, enable Bluetooth and select “**QCY-T13.**”
3. When pairing succeeds, the buds will reconnect to this phone whenever you open the lid.

Make the Earbuds Discoverable Again

If you need to pair to a second device:

1. With the original phone disconnected, *insert both earbuds into the case.*
2. **Press-and-hold** the touch panel on *either* earbud for ≈ 10 s until its LED flashes **green 3x.**
3. Take them out—the LEDs blink red/blue and the buds are now discoverable.

Factory Reset

Keep the earbuds in the case, then **press-and-hold the case button for 10 s.** Both earbud LEDs flash **red** → **blue (3x)** and all pairing records are erased.

LED Guide

Location	Indicator	Meaning
Earbud	Solid red	Charging in case
	Solid blue (1 min.)	Fully charged
Case	Solid red	Case charging
	Solid green	Case topped up

Charging

1. Earbuds: ~2 h to full when placed in the case.
2. Case: Charge with a 5 V=0.4 A USB-C adapter; LEDs show status (see table above).

Safety & Care Tips

Read these instructions and keep them for reference.

1. If stored for > 2 months, fully charge the earbuds at least once.
2. Remove the earbuds every ~2 h to let your ears rest.
3. Clean the charging pins with a soft dry cloth to maintain good contact.
4. High-volume listening for prolonged periods can damage hearing—listen responsibly.

Cautions

- Never disassemble, modify, or incinerate the product.
- Do not use or store it in temperatures below -10 °C or above 45 °C, or during thunderstorms.
- Avoid dropping or submerging the device.