## Shinecon G04 Bluetooth Gamepad User Manual



## **Specifications:**

- Bluetooth version: v3.0


Operating range: up to 10mBattery capacity: 300mAh

- Play time: around 30h

- Phone holder: 50mm - 80mm

- Supported OS: Android

- Dimensions: 153mm x 108mm x 53mm



- 1. Select key
- 2. Power on/off
- 3. Left joystick
- 4. Direction keys
- 5. L1
- 6. L2
- 7. L3 (left joystick push down)
- 8. R1
- 9. R2
- 10. Mode
- 11. Start key
- 12. ABXY keys
- 13. Right joystick
- 14. R3 (right joystick push down)
- 15. Indicator light
- 16. USB
- 17. Reset

## **Operation instruction:**

- Press the power button to turn it on (activate the last using mode)
- Press and hold the power button to turn it off
- Auto turn off after 3min without connection with your device
- Auto turn off after 15min without using the gamepad
- Press and hold "A+Power" button to activate the Android mode
- Activate the Bluetooth on your device and search for gamepad name (example SC-G04-XX)