Electric Blackhead Remover Vacuum Pore Cleaner



Specifications:

- Material: ABS

Input power: 2.5WSuction: up to 62KPa

Battery: 6000mAhWorking voltage: 5VCharging voltage: 5VUsage time: about 90min

- Power supply: USB charging cable

- Dimensions: 180 x 45mm




- 1. Replaceable suction head
- 2. Display
- 3. On/Off button
- 4. Mode suction adjustment (M) button

Six replaceable heads:

- 1. Elliptical hole beauty suction head
- Mainly used for removing fine lines, increasing skin elasticity.
- 2. Microcrystalline beauty suction head
- Fine crystals gently remove aging cutin and make skin smooth and elastic.
- 3. Big round hole cosmetic suction cup
- It is used to suck blackhead tightly on the V face, and needs to move back slowly on the skin. Do not use it in one place for a long time.
- 4. Medium round hole cosmetic suction head
- High suction, used to absorb blackhead, acne grease too much. Use from the bottom to the top pull, from the chin up slowly. Do not use it in one place for a long time.

- 5. Small round hole beauty suction head
- Small suction, used to suck blackheads for thin and tender skin.
- 6. Mini round hole beauty suction head
- Less suction for sensitive skin or blackheads.



Using steps:

- 1. Before use, please use hot towel, hot compress or export liquid to open the pore and then use it again
- 2. Install the suction head on the machine
- 3. Press the switch button to start, then press M button to select suction force. Buttons are boot default to middle (ZX neutral skin), long press (GX oily skin), short press (YX dry skin). You can test the strength on your arm.
- 4. The suction head moves slowly on the skin. Do not stay in the same area for too long.