

User Manual for OnePlus Buds True Wireless Earphones 5481100037



Specifications

- Driver: 13,4mm dynamic
- Earbud weight: 4,7g
- Frequency response range: 20Hz - 20kHz
- Bluetooth version: BT 5.0
- Charging interface: Wired: USB Type-C
- Rated capacity: Charging box: 420mAh
- Microphone sensitivity: 38 dB ± 2dB
- Protection: Spray safe, IPX4
- Wireless range: 10m
- Time to fully charge earbuds+charging box: 80 min
- Earbud battery: 35mAh (per earbud)
- Fast charge: 10 mins for 10 hours (charging box+earbuds) / 10 mins for 2 hours playtime for the earbuds

Connection and Use

Open the charging box to turn on the OnePlus Buds. Place them in the charging box and close the cover to turn them off.

Before pairing with a new device or reconnecting, please turn on the GPS location information, Wi-Fi / Mobile data, and Bluetooth in the notification bar menu or phone settings.

While the buds are inside the charging box, open the charging box and press and hold the setup button for 2 seconds. The indicator lamp of the charging box will flash white. The buds will then be available for pairing.

- If the box is being opened for the first time, OnePlus Buds will automatically be available for pairing. If an OnePlus phone is used, the phone will automatically pop up an animation about connecting the buds. Follow the prompts to connect the phone with the OnePlus Buds.
- After factory settings are restored, pairing records will be erased. If the box is being opened for the first time, OnePlus Buds will automatically be available for pairing.

If an OnePlus or Android phone with a Fast Pair function is being used, enable Bluetooth on the phone, and open the charging box for the OnePlus Buds. The phone will automatically pop up an animation about connecting the buds. Follow the prompts to connect the phone with OnePlus buds.

After OnePlus Buds have been successfully paired with a device, the buds will automatically reconnect to the device each time the buds start. If reconnection fails, open the Bluetooth setting on the device, tap Previously Connected Devices and search for OnePlus Buds, and tap the buds to connect them.

If the OnePlus Buds have been disconnected from your device because you're too far, and you return to the effective distance of the connection within 10 minutes, OnePlus Buds will automatically reconnect with your device. If there is no reconnection for 10 minutes, the buds will automatically shut down. In this case, you can put the buds into the charging box, close the cover, and then open it to reconnect them.

Functions and Operations

Call functions:

- Answer a call: double-tap the touch area of the bud.
- Hang up a call: double-tap the touch area of the bud.
- Reject a call: tap and hold the touch area of the bud for 5 seconds.

Music/standby:

- Double-tap the left or right bud to play the next track by default.
- On the OnePlus phone, go to Bluetooth & Device Connection - Previously Connected Devices, tap the OnePlus Buds settings icon to customize the double-tap function in the device details interface. (Note: Currently, this feature is only available on OnePlus 6 or newer versions.)
- Optional functions: Play/pause, next track, previous track, and wake up the default voice assistant.

Charging the EarBuds and the Box

If the buds are placed in the charging box, the indicator lamp will show the battery level of the buds, and ignore the battery level of the charging box. Take the buds out. The indicator lamp will show the battery level of the charging box.

To charge them, put the buds in the charging box: The charging contacts at the bottom of the buds' handle must be clean, otherwise charging and use may be affected.

You can connect the charging box to a power supply through the power cable delivered with the buds to charge it. If the indicator lamp of the charging box is always red, the charging box is charging. If it is green, the charging box is fully charged.