Dual Lens Wide-Angle Full HD Mirror Dash Cam & HD Rear Camera



Specifications:

- Resolution: 1080p (front); 720p (rear)
- Display: 4.39" touchscreen
- FOV: 170-degree; 110-degree

- Supported memory cards: MicroSD up to 32GB (not included)
- Input: DC 5V/1.2-2A
- Battery capacity: 400mAh
- Supported languages: English, French, German, Russian, Japanese, Chinese, etc.

Device structure:

- 1. USB interface
- Connect it with your PC or connect the external power supply
- 2. Rear camera interface
- Connect the rear camera
- 3. TF card slot
- Insert your memory card (supported MicroSD up to 32GB)
- 4. GPS interface reserved
- Connect your GPS antenna
- 5. OK button

- Video and photo confirmation button. Video mode: press it to start the video, press it again to stop the video. Photo mode: press it to take photos

- 6. Down select button
- Press it to navigate down within menu
- 7. Up select button
- Press to navigate up within menu
- 8. Mode button / menu button
- Press it to switch between camera, photo, playback. Long press to open the menu.
- 9. On/Off button
- Press it to turn the camera on/off
- 10. LCD screen
- View your videos and photos
- 11. Reset
- Restart the camera
- 12. Horn
- Play video or sound amplification hole files, operating sound warning
- 13. Back clip fixation hook
- 14. Camera lens

Battery charging

While the battery is charging, the red indicator is on, showing the charging status. The charging time is about 180 minutes, and the red charging indicator will automatically go off when the charging is completed. You can charge the camera using a power adapter, car charger or PC via a USB cable.