User manual for Xiaomi Mi 70mai Pro Smart WiFi Dash Camera



Specifications:

- Video resolution: 2592x1944px (1944p)
- Frame rate: 30fps
- Display: 2" IPS
- Battery capacity: 500mAh
- WiFi frequency: 2.4GHz
- Max. distance: 6m
- FOV angle: 140 degrees
- Output ports: AV, HDMI
- Dimensions: 8.75 x 5.30 x 1.80cm

Installation

Please install the dashcam following the method below:

1. Install the electrostatic sticker

Take out the electrostatic sticker from the packing box and install it in the recommended area on the windshield, as shown in the figure below.

Please clean the windshield, and remove the air bubbles between the electrostatic sticker and the windshield during the installation.



2. Connect the Dash Cam Pro to the bracket

Lock the bracket to the Dash Cam Pro, as shown in the figure below. You will hear a snap when it is in place.



3. Attach the Dash Cam Pro

Remove the protective sticker on the Dash Cam Pro bracket and attach the Dash Cam Pro to the center of the electrostatic sticker, as shown in the figure below.

Press the bracket mount by hand to ensure that the heat resistant adhesive is in close contact with the electrostatic sticker.



4. Connect the power supply

As shown in the figure, run the power cable along the top of the windshield, down pillar A, and around the passenger-side glove compartment. Arrange the end so that it runs to the cigarette lighter port. After connecting it to the car charger, plug the charger into the port.



5. Adjust the Dash Cam Pro angle

Turn on the Dash Cam Pro and adjust the camera angle up and down against the preview screen to ensure that the camera is facing the front.

Activating 70mai Smart Dash Cam Pro

The 70mai Smart Dash Cam Pro must be activated using the 70mai app. To do so, please visit the https://www.70mai.com/en/download/ website to download and install the 70mail app.

Please select "Add Device" in the 70mail app and complete the activation according to the prompts.