


Baseus Streamer F40 FM Transmitter / Car Charger CCF40-01



Specifications:

- Input voltage: DC 12-24V
- Charging port max current: 5V / 2A
- Max charging power: 15W
- Max total charging current: 3A
- FM frequency: 76-108MHz

- FM distance: up to 5m
- Bluetooth version: 5.0
- Bluetooth range: up to 10m
- Max supported flash drive: 64GB
- Supported audio formats: mp3, ape, flac, wac
- AUX cable length: 60cm
- Dimensions: 95 x 48 x 45 mm
- Weight: 36g



1. Microphone
2. Display
3. Multifunctional switch (play/pause/previous/next mode switching)
4. USB charging output
5. USB for flash disk/charging
6. AUX audio output

Start-up

- Plug the FM transmitter into the car cigarette lighter socket to power it on. It will show the current car battery voltage for 2 seconds. After that, it enters the local or wireless music playback state.

Bluetooth connection

1. Power on the FM transmitter
2. Turn on your smartphone's Bluetooth, search for F40 and pair it
3. Then you can use the Bluetooth function to play music from your smartphone or answer a call
4. After successful connection for the first time, it will automatically memorize the phone

FM transmission frequency modulation

1. Insert the FM transmitter into the cigarette lighter port and turn on the FM radio.
2. Long press the multifunction button to make the FM radio frequency point flash.
3. Toggle the multifunction button up/down to increase/decrease the FM radio frequency and switch to a channel without signal interference, the screen displays the switched channel.
4. Then, fine-tune the car radio device to ensure that their frequency bands are on the same point.

Hands-free function

- Answer the call: short press the multifunction button
- Reject the call: long press the multifunction button
- Call back: quick press the multifunction button twice to call back the last phone number you had a conversation with

Music playing mode

- Press the multifunction button to pause or play music
- Toggle the multifunction button up/down to switch songs
- Toggle and hold the multifunction button up/down to adjust the volume
- Press and hold for 2sec the multifunction button to change the music mode